
### 3-6. Other interior features


### Sun visors



- 1 Forward position: Flip down.
- Side position: Flip down, unhook, and swing to the side.

At this position, the visors can be slid backward.

# Vanity mirror



1 Open

The light turns on when the cover is opened.

2 Adjust the brightness of the light

### 3-6. Other interior features

### Clock



- 1 Adjusts the hour.
- 2 Adjusts the minutes.
- Rounds to the nearest hour.\*

\*: e.g. 1:00 to 1:29 
$$\rightarrow$$
 1:00  
1:30 to 1:59  $\rightarrow$  2:00

### ■ The clock is displayed when

The engine switch is in the ACC or ON position.

Interior features

### Outside temperature display



Displays the outside air temperature

The temperature range that can be displayed is from -22°F (-30°C) to 122°F (50°C).

If the temperature does not appear or it shows

Have the vehicle inspected by your Lexus dealer.

## Multi-display light control



Adjusts the brightness of the light

Push and release the button until the desired brightness is obtained.

#### The power outlet can be used for a following component.

12 V: Accessories that run on less than 10 A. 115 VAC: Audio device that use less than 100 W.

► On center cluster (12 V)




► Tray under the front console box (12 V)



► Luggage compartment (12 V)



### ► Luggage compartment (115 VAC)\*



\*: If equipped

Main switch

To use the power outlet, turn on the main switch.

Power outlet socket

#### ■ The power outlet can be used when

▶ 12 V

The engine switch is in the ACC or ON position.

▶ 115 VAC

The engine switch is in the ON position.

### **⚠** NOTICE

#### ■ To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

#### ■ To prevent the fuse from being blown

▶ 12 V

Do not use an accessory that uses more than  $12\ V\ 10\ A$ .

► 115 VAC

Do not use a 115 VAC appliance that requires more than 100 W.

If a 115 VAC appliance that consumes more than 100 W is used, the protection circuit will cut the power supply.

### **♠** NOTICE

#### ■ To prevent the battery from being discharged

Do not use the power outlet longer than necessary when the engine is not running.


#### ■ Appliances that may not operate properly (115 VAC)

The following 115 VAC appliances may not operate properly even if their power consumption is under 100 W.

- Appliances with high initial peak wattage
- Measuring devices that process precise data
- Other appliances that require an extremely stable power supply

#### 3-6. Other interior features

### Seat heaters (if equipped)



- 1 Pops the switch out
- 2 ON

The indicator light comes on.

3 Adjusts the seat temperature

The further you turn the knob clockwise, the warmer the seat becomes.

#### ■ The seat heaters can be used when

The engine switch is in the ON position.

#### ■ When not in use

Turn the knob counterclockwise. The indicator light turns off. Press the knob into the recessed position.

### **A** CAUTION

#### ■ Burns

- Use caution when seating the following persons in a seat with the seat heater on to avoid the possibility of burns:
  - · Babies, small children, the elderly, the sick and the disabled
  - Persons with sensitive skin
  - Persons who are fatigued
  - Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Do not cover the seat with anything when using the seat heater.
   Using the seat heater with a blanket or cushion increases the temperature of the seat and may lead to overheating.

### **⚠** NOTICE

#### ■ To prevent seat heater damage

Do not put unevenly weighted objects on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.

#### ■ To prevent battery discharge

Turn the switches off when the engine is not running.

### **Armrest**





Pull the armrest down for use.

#### Rear




Pull the armrest down for use.

### **№** NOTICE

### ■ To prevent damage to the armrest

Do not place too much strain on the armrest.

### Securely place a mat that matches the size of the space on the carpet.



Secure the driver's floor mat using the hooks provided.

### **A** CAUTION

#### ■ When inserting the floor mat

Make sure the floor mat is properly placed on the vehicle carpet.

If the floor mat slips and interferes with the movement of the pedals during driving, it may cause an accident.


### Luggage compartment features

### ■ Cargo hooks



Cargo hooks are provided for securing loose items.

### Auxiliary box




To lift the luggage mat up, press down the button.

An auxiliary box is under the luggage mat.

■ Shopping bag hooks



#### ■ Luggage cover



Attach the hooks to the head restraints.



Pull out the luggage cover and hook it onto the anchors.

### Removing luggage cover




- 1 Push
- 2 Lift up

After removing the luggage cover, stow it in the auxiliary box or place it somewhere other than the passenger compartment.

#### Automatic retract function of luggage cover

The knob is in the active position, the luggage cover is retracted automatically when the back door is opened.



- Active position
- Inactive position



■ When the cargo hooks are not in use

To avoid injury, always return the cargo hooks to their positions when they are not in use.

### **↑** NOTICE

■ Shopping bag hook weight capacity

Do not hang any object heavier than  $4 \, \text{lb.} (2 \, \text{kg})$  on shopping bag hooks.

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, and security systems, and other devices.

The garage door opener (HomeLink  $^{\circledR}$  Universal Transceiver) is manufactured under license from HomeLink  $^{\circledR}$ .

### Programming the HomeLink® (for U.S.A. owners)

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.



- Buttons
- 2 Indicator

■ Programming the HomeLink®



Point the remote control for the device 1 to 3 in. (25 to 75 mm) from the HomeLink<sup>®</sup> control buttons.

Keep the indicator light on the  $\mathsf{HomeLink}^{\mathbb{B}}$  in view while programming.





Press and hold down one of the buttons on the HomeLink<sup>®</sup> and the button on the transmitter. When the indicator light on the HomeLink<sup>®</sup> changes from a slow to a rapid flash after 20 seconds, you can release both buttons.

Test the operation of the HomeLink<sup>®</sup> by pressing the newly programmed button.

If programming a garage door opener, check to see if the garage door opens and closes. If the garage door does not operate, see if your garage transmitter is of the Rolling Code type. Press and hold the programmed HomeLink® button. The garage door has the rolling code feature if the indicator light (on the HomeLink®) flashes rapidly for 2 seconds and then remains lit. If your transmitter is the Rolling Code type, proceed to the heading "Programming a rolling code system".

Repeat the steps above to program another device for each of the remaining HomeLink<sup>®</sup> buttons.

### ■ Programming a Rolling Code system (for U.S.A. owners)

If your device is Rolling Code equipped, follow the steps under the heading "Programming the HomeLink®" before proceeding with the steps listed below.

STEP 1 Locate the training button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener.

Refer to the operation manual supplied with the garage door opener for the location of the training button.

- STEP 2 Press the training button.
- Press and release the vehicle's programmed HomeLink<sup>®</sup> button twice. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink  $^{\circledR}$  transceiver and operate the garage door.

- STEP 4 Repeat the steps above to program another rolling code system for any of the remaining HomeLink<sup>®</sup> buttons.
- Programming an entry gate (for U.S.A. owners)/Programming all devices in the Canadian market
- STEP 1 Place your transmitter 1 to 3 in. (25 to 75 mm) away from the surface of the HomeLink  $^{\circledR}$ .

Keep the indicator light on the HomeLink® in view while programming.

- STEP 2 Press and hold the selected HomeLink® button.
- Repeatedly press and release (cycle) the device's remote control button for two seconds each until step 4 is complete.
- STEP 4 When the indicator light on the HomeLink $^{\mathbb{R}}$  compatible transceiver start to flashing rapidly, release the buttons.

- Test the operation of the HomeLink<sup>®</sup> by pressing the newly programmed button. Check to see if the gate/device operates correctly.
- Repeat the steps above to program another device for each of the remaining HomeLink<sup>®</sup> buttons.

#### ■ Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your authorized Lexus dealer for assistance.

### ■ Reprogramming a button

The individual HomeLink $^{\circledR}$  buttons cannot be erased but can be reprogrammed. To reprogram a button, follow the "Programming the HomeLink $^{\circledR}$ " instructions.

### Operating the HomeLink®

Press the appropriate  $\mathsf{HomeLink}^{\otimes}$  button. The  $\mathsf{HomeLink}^{\otimes}$  indicator light on the  $\mathsf{HomeLink}^{\otimes}$  transceiver should turn on.

The HomeLink $^{(8)}$  continues to send a signal for up to 20 seconds as long as the button is pressed.

### Erasing the entire HomeLink® memory (all three programs)



Press and hold down the 2 outside buttons for 20 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the HomeLink<sup>®</sup> memory.

#### ■ Before programming

- Install a new battery in the transmitter.
- The battery side of the transmitter must be pointed away from the HomeLink<sup>®</sup>.

#### ■ Certification for the garage door opener

This device complies with Part 15 of the FCC Rules and with RSS-210 of the IC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: This transmitter has been tested and complies with FCC and IC rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

### **A** CAUTION

#### ■ When programming a garage door or other remote control device

The garage door may operate, so ensure people and objects are out of danger to prevent potential harm.

#### ■ Conforming to federal safety standards


Do not use the HomeLink<sup>®</sup> Compatible Transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards.

This includes any garage door that cannot detect an obstruction object. A door or device without these features increases the risk of death or serious injury.

### Compass

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

### ■ Operation




1 To turn the compass on or off, press the switch.

### ■ Displays and directions

Display	Direction
N	North
NE	Northeast
E	East
SE	Southeast
S	South
SW	Southwest
W	West
NW	Northwest

#### Calibrating the compass




The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.

If you cross over a map boundary shown in illustration, the compass will deviate.

To obtain higher precision or perfect calibration, refer to the following.

#### ■ Deviation calibration

STEP 1 Stop the vehicle where it is safe to drive in a circle.



Press the switch until a number (1 to 15) appears on the compass display.

Press the switch, and referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.

#### ■ Circling calibration



When C appears on the display, drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until the direction is displayed.

#### ■ Conditions unfavorable to correct operation

The compass may not show the correct direction in the following conditions:

- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized.
   (There is a magnet or metal object near the inside rear view mirror.)
- The battery has been disconnected.
- A door is open.

#### **CAUTION**

#### ■ While driving the vehicle

Do not adjust the display. Be sure to adjust the display only when the vehicle is stopped.

#### ■ When doing the circling calibration

Be sure to secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.



#### NOTICE

#### ■ To avoid the compass malfunctions

Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause a malfunction of the compass sensor.

#### ■ To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.